

## Safety advice on the operation of pole stands

1. Conduct your job site-based risk assessment
2. Ensure the stands are free of any damage –  
Bent, twisted, damaged stands should be removed from service
3. Ensure all securing hardware is in place and stickers are legible
4. Ensure pole weight, ground conditions, and condition of pole stand are all considered before use
5. Never place any part of your body between the ground and the pole while on the stand.
6. Ensure area is kept clear at all times of trip hazards
7. **Pole stand must be set on hard, level ground.** Refer your company work practices and dunnage procedures if ground is not considered hard (>200kPa bearing).
8. Ensure chain is extended **AND** locking leg is locked into rear leg before loading pole



For further information refer to the compliance plate on stand and risk assessment using the QR-code or contact us at <https://www.tengroup.com.au/contact>